



AXLE SEALS

FEATURES & BENEFITS

- » Passes SAE J110 hot, cold and slurry tests for extended seal life
- » TS-16949 and ISO9001 certified

RELATED PARTS

- » U-Joints
- » End Yokes
- » Axle Shafts
- » Carriers



AXLE SEALS

The main function of axle seals is to contain oil, while preventing contaminants from entering the housing. During the installation, it is recommended to use the proper seal driver and sleeve drive tools. Eleven axle seals have been added to the TRP program, covering the most popular ArvinMeritor and Dana axle specifications.

CROSS REFERENCE & INSTALLATION TOOLS

Seal	Axle Model & Position	OEM Cross Reference	Seal Driver/Service Kit
AS2728	Forward Rear Input, 14X, 16X, 18X	A1-1205X2728	2728T1
AS2729	Forward Rear Output, 14X, 16X	A1-1205Y2729	2729T1
AS2730	Rear Rear Input, 14X	A1-1205Z2730	2730T1
AS2731	Rear Rear Input, 16X, 18X	A1-1205A2731	2731T1
AS7000	Forward Input, 344, 404, 405, 454, DSP40	127591	217414
AS7001	Forward Output, 344, 404, 405, 454, DSP40	127592	217414
AS7002	Forward Input, 341, 381, 402, 451	127719	212139
AS7003	Forward Output, 341, 381, 402, 451	127720	212139
AS7004	Forward Input, 46K to 65K, 461	210736	217590
AS7005	Forward Output, 46K to 65K, 461	210737	217590
AS7006	Output Shaft 461	210724	217590



Scan the code for more information.
Get the free mobile app at <http://gettag.mobi>